

Manual

The pre-filter/skimmer basket is placed inside the filter after the rings have been installed according to the drawing below.

